

DOWN TO HANG

Attached hanger creates a pop-up dressing station, not a pile on the ground

SMALL WORLD

Flexible mesh pockets hold the tiniest items

STAY FRESH

Each mesh pod holds a reVIVE activated charcoal pack to fight odor and humidity

WASH AND WEAR

Detachable laundry bag unzips right into your laundry load



PERFECT CLARITY

Two clear pockets track your essentials at a glance

TAKE IT TO GO

Storage pods attach with snag-free hook and loop fasteners to hold pointe shoes, street shoes or your go-to footwear

SMART STORAGE

Mesh compartments promote airflow and organization

CROSS TRAIN

Lightweight straps convert to backpack, cross-body, shoulder strap and even trolley sleeve for travel, adjusting to your comfort and preferences



**CROSS-BODY
SHOULDER STRAP**



BACKPACK



TROLLEY SLEEVE